













































Original	Replacement
	Power
	3D
	TV
	TV
	1
	2
	3
	4
	5
	6
	7
	8
	9
	Eco
	0
	Source
	Vol+


































Original	Replacement
	Mute
	P+
	Vol-
	P-
	Info
	Option
	Smart Tv
	Guide
	Menu
	Up
	Left
	OK
	Right
	Back
	Down
	Exit
	Zoom-

Original	Replacement
	Power
	Shift + 3
	Shift + 1
	TV/Radio /
	1
	2
	3
	4
	5
	6
	7
	8
	9
	Display / Media
	0
	AV / Input / RDS
	Vol+

Original	Replacement
	Mute / Dimmer
	CH+ / Page+
	Vol-
	CH- / Page-
	Info / Angle
	Setup / OPT /
	Smart / List
	Guide / EPG / -/-
	Menu / Home
	Up
	Left
	OK
	Right
	Back / Return
	Down
	Exit / Cancel / Clear
	Shift + Down





Original	Replacement	Original	Replacement
 Zoom+	 Shift + Up	 >	 >>  / Preset+
 @/Home	 D.Menu / Top	 <<	 << / Tune-
 Sleep	 Sleep / Timer	 Rec	 Rec / Rec Mode
 Pre-CH	 Shift + Back / Return	 >>	 >> / Tune+
 FAV	 Fav / Marker / PC		
 List	 Shift + Smart / List		
 Red	 Red / Netflix / Search		
 Green	 Green / APP / Repeat		
 Yellow	 Yellow / YouTube / Repeat		
 Blue	 Blue / Prime Video / Random		
 OO/Lang	 Audio / Lang I/II		
 Subtitle	 Subtitle / EQ		
 Text	 Text / Goto		
 I<	 I<< / Preset-		
 Stop	 Stop / Hold		
 Play	 Play / Slow		
 Pause	 Pause / Step / Freeze		

