































Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
	Power		Power
	Mute		Mute
	Vol+		Vol +
	Vol-		Vol -
	Bass+		Ch +
	Bass-		Ch -
	TV		TV/R
	AUX		AV
	Bluetooth		Smart
	Movie		Media
	Night		Guide
	Music		Dual
	Dialog Enhancer 1		1
	Dialog Enhancer 2		2
	Dialog Enhancer 3		3

