















































Originalfernbedienung Ersatzfernbedienung

	Power		Power
	TV		Shift + 1
	Tuner/Band		Shift + 6
	FM Mode		TV/Radio /
	DVD/CD		Shift + 3
	DVD/CD		Shift + 2
	I<</Skip Down		I<< / Preset-
	Power VCR		Shift + Power
	>>I / Skip Up		>>I / Preset+
	TV / AV		AV / Input / RDS
	<< Slow/Search		<< / Tune-
	Slow/Search >>		>> / Tune+
	Stop		Stop / Hold
	Pause		Pause / Step / Freeze
	Play		Play / Slow
	Top Menu		D.Menu / Top
	Up		Up

Originalfernbedienung Ersatzfernbedienung

	Menu		Menu / Home
	Left		Left
	Enter / Set		OK
	Right		Right
	OSD		Smart / List
	Down		Down
	Return		Back / Return
	Angle		Info / Angle
	RDS		Shift + AV / Input / RDS
	Timer		Sleep / Timer
	Setup		Setup / OPT /
	Audio		Audio / Lang I/II
	Subtitle		Subtitle / EQ
	Play Mode		Picture / Format
	1		1
	2		2
	3		3





Originalfernbedienung Ersatzfernbedienung

	Display		Display / Media
	4		4
	5		5
	6		6
	A-B Repeat		Yellow / YouTube / Repeat
	7		7
	8		8
	9		9
	Repeat		Green / APP / Repeat
	Cancel		Exit / Cancel / Clear
	0		0
	-/-/ >10		Guide / EPG / -/-
	Position		CH+ / Page+
	Center Focus		CH- / Page-
	Subwoofer		Shift + Eject / Surround
	D.MIX		Blue / Prime Video / Random
	Dolby PL		Sound / Title

Originalfernbedienung Ersatzfernbedienung

	CH Select		Red / Netflix / Search
	SFC		Zoom / Size
	Test		Text / Goto
	Muting		Mute / Dimmer
	Super Surround		Eject / Surround
	Vol-		Vol-
	Vol+		Vol+

