





































Originalfernbedienung Ersatzfernbedienung

| | | | |
|---|-----------|---|--------|
|  | Power STB |  | Power |
|  | << |  | << |
|  | Play |  | Play |
|  | Pause |  | Pause |
|  | >> |  | >> |
|  | l< |  | l<< |
|  | >l |  | >>l |
|  | Stop |  | Stop |
|  | Red |  | Red |
|  | Green |  | Green |
|  | Yellow |  | Yellow |
|  | Blue |  | Blue |
|  | Video |  | Format |
|  | Menu |  | Menu |
|  | i |  | Info |
|  | Up |  | Up |


















Originalfernbedienung Ersatzfernbedienung

| | | | |
|---|-------|---|--------------|
|  | Left |  | Left |
|  | OK |  | Ok |
|  | Right |  | Right |
|  | Down |  | Down |
|  | Back |  | Back |
|  | Guide |  | Guide |
|  | X |  | Exit |
|  | Vol+ |  | Vol + |
|  | Vol- |  | Vol - |
|  | ↑ |  | Shift + Up |
|  | ↓ |  | Shift + Down |
|  | CH+ |  | Ch + |
|  | CH- |  | Ch - |
|  | Mute |  | Mute |
|  | P < P |  | Pre Ch |
|  | 1 |  | 1 |
|  | 2 |  | 2 |













Originalfernbedienung Ersatzfernbedienung

| | | |
|-------------|---|---------|
| PWR On/Off |  | Power |
| Epg |  | Guide |
| Subt.List |  | Subt |
| Opt? |  | Options |
| App |  | Media |
| Sleep Timer |  | Sleep |
| TV |  | TV/R |
| Text |  | Text |
| Zoom |  | Eject |
| Menu |  | Menu |
| Menu Up |  | Up |
| Menu Left |  | Left |
| OK Enter |  | Ok |
| Menu Right |  | Right |
| Menu Down |  | Down |
| Back |  | Back |
| CH/Page+ |  | Ch + |
















Originalfernbedienung Ersatzfernbedienung

| | | |
|-----------|---|--------|
| Audio |  | Dual |
| CH/Page- |  | Ch - |
| 1. ? |  | 1 |
| 2abc |  | 2 |
| 3def |  | 3 |
| 4ghi |  | 4 |
| 5jkl |  | 5 |
| 6mno |  | 6 |
| 7pqrm |  | 7 |
| 8tuv |  | 8 |
| 9wxyz |  | 9 |
| 0/10 |  | 0 |
| FAV Pref. |  | Pre Ch |
| Red |  | Red |
| Green |  | Green |
| Yellow |  | Yellow |
| Blue |  | Blue |






















Originalfernbedienung Ersatzfernbedienung

| | | |
|------------|---|---------|
| PWR On/Off |  | Power |
| Mute |  | Mute |
| Opt? |  | Options |
| App |  | Media |
| Subt.List |  | Subt |
| Info |  | Info |
| Video |  | D. Menu |
| Zoom |  | Eject |
| Menu |  | Menu |
| Menu Up |  | Up |
| Menu Left |  | Left |
| OK Enter |  | Ok |
| Menu Right |  | Right |
| Exit |  | Exit |
| Menu Down |  | Down |
| Back |  | Back |
| Volume+ |  | Vol + |

Originalfernbedienung Ersatzfernbedienung

| | | |
|--------------|---|--------|
| CH/Page+ |  | Ch + |
| Volume- |  | Vol - |
| Audio |  | Dual |
| CH/Page- |  | Ch - |
| 1. ? |  | 1 |
| 2abc |  | 2 |
| 3def |  | 3 |
| 4ghi |  | 4 |
| 5jkl |  | 5 |
| 6mno |  | 6 |
| 7pqrm |  | 7 |
| 8tuv |  | 8 |
| 9wxyz |  | 9 |
| Guide Pilote |  | Guide |
| 0/10 |  | 0 |
| FAV Pref. |  | Pre Ch |
| Red |  | Red |



