

































































Originalfernbedienung Ersatzfernbedienung

|   |       |   |        |
|---|-------|---|--------|
|    | Power |    | Power  |
|    | PP    |    | Pre Ch |
|    | Mute  |    | Mute   |
|    | I-II  |    | Dual   |
|    | P<P   |    | Back   |
|    | -/--  |    | Guide  |
|    | 1     |    | 1      |
|    | 2     |    | 2      |
|    | 3     |    | 3      |
|    | 4     |    | 4      |
|    | 5     |    | 5      |
|   | 6     |   | 6      |
|  | 7     |  | 7      |
|  | 8     |  | 8      |
|  | 9     |  | 9      |
|  | 0     |  | 0      |
|  | Vol+  |  | Vol +  |

Originalfernbedienung Ersatzfernbedienung

|   |                |   |        |
|---|----------------|---|--------|
|    | Vol-           |    | Vol -  |
|    | Up             |    | Up     |
|    | Down           |    | Down   |
|    | Right          |    | Right  |
|    | Left           |    | Left   |
|    | M              |    | Ok     |
|    | PR+            |    | Ch +   |
|    | PR-            |    | Ch -   |
|    | M              |    | Menu   |
|    | Red/Sound      |    | Red    |
|    | Green/Picture  |    | Green  |
|   | Yellow/Feature |   | Yellow |
|  | Blue/Install   |  | Blue   |
|  | TV             |  | TV/R   |
|  | AV             |  | AV     |
|  | [≡]            |  | Text   |
|  | [≡o]           |  | Smart  |



