



Originalfernbedienung Ersatzfernbedienung

	Power		Power
	Mute		Mute / Dimmer
	Input Tv		AV / Input / RDS
	Input Bluetooth		9
	Vol+		Vol+
	Sub-woofer+		CH+ / Page+
	Vol-		Vol-
	Sub-woofer-		CH- / Page-
	Sound Mode		Sound / Title

Originalfernbedienung Ersatzfernbedienung

