




**Originalfernbedienung Ersatzfernbedienung**

|   |                 |   |                          |
|---|-----------------|---|--------------------------|
|    | Standby         |    | Power                    |
|    | Tv Operate      |    | Shift + Power            |
|    | CH+ Tv          |    | Shift + CH+ /            |
|    | Vol+ Tv         |    | Vol+                     |
|    | Timer On/Off    |    | Sleep / Timer            |
|    | Input Select Tv |    | Shift + AV / Input / RDS |
|    | CH- Tv          |    | Shift + CH- /            |
|    | Vol- Tv         |    | Vol-                     |
|    | Menu            |    | Menu / Home              |
|    | Up              |    | Up                       |
|    | Set             |    | Setup / OPT /            |
|    | SV/V+/Timer     |    | Picture / Format         |
|  | Left            |  | Left                     |
|  | Right           |  | Right                    |
|  | Down            |  | Down                     |
|  | Clear           |  | Exit / Cancel / Clear    |
|  | <</REW          |  | << / Tune-               |

**Originalfernbedienung Ersatzfernbedienung**

|   |             |   |                       |
|---|-------------|---|-----------------------|
|    | Play/X2     |    | Play / Slow           |
|    | >>/FF       |    | >> / Tune+            |
|    | Rec         |    | Rec / Rec Mode        |
|    | Stop        |    | Stop / Hold           |
|    | Pause/Still |    | Pause / Step / Freeze |
|    | Tape Speed  |    | Zoom / Size           |
|    | Audio Out   |    | Audio / Lang I/II     |
|    | 1           |    | 1                     |
|    | 2           |    | 2                     |
|    | 3           |    | 3                     |
|    | Mode OSD    |    | Text / Goto           |
|    | 4           |    | 4                     |
|  | 5           |  | 5                     |
|  | 6           |  | 6                     |
|  | Display     |  | Display / Media       |
|  | 7           |  | 7                     |
|  | 8           |  | 8                     |



