

































Originalfernbedienung Ersatzfernbedienung

	Power		Power
	Mute		Mute / Dimmer
	DTV		Shift + 1
	Radio		TV/Radio /
	USB		Shift + 8
	DVD		Shift + 2
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	TV Guide		Guide / EPG / -/--
	0		0

Originalfernbedienung Ersatzfernbedienung

	Recall		Back / Return
	Vol +		Vol+
	P.Mode		Picture / Format
	CH +		CH+ / Page+
	Vol -		Vol-
	S.Mode		Sound / Title
	CH -		CH- / Page-
	FAV		Fav / Marker / PC
	Menu		Menu / Home
	Up		Up
	Exit		Exit / Cancel / Clear
	Left		Left
	OK		OK
	Right		Right
	Source		AV / Input / RDS
	Down		Down
	Info		Info / Angle





Originalfernbedienung	Ersatzfernbedienung
ASPECT Aspect	SHIFT + FORMAT PICTURE Shift + Picture / Format
SLEEP Sleep	TIMER SLEEP Sleep / Timer
AUDIO Audio	LANG I/II AUDIO Audio / Lang I/II
SUBTITLE Subtitle	EQ SUBTITLE Subtitle / EQ
TEXT Text	GOTO TEXT Text / Goto
TEXT HOLD Text Hold	SHIFT + HOLD Shift + Stop /
TEXT ZOOM Text/DVD Zoom	SIZE ZOOM Zoom / Size
DISP. POWER Display Power	MEDIA DISPLAY Display / Media
DISP. POWER Display Power	SHIFT + POWER Shift + Power
DVD MENU Rec / DVD Menu	TOP MENU D.MENU D.Menu / Top
DVD MENU Rec / DVD Menu	REC MODE Rec / Rec Mode
I<<	PRESET- I<< / Preset-
>>I	PRESET+ >>I / Preset+
Stop / Open/Close	SURROUND Eject / Surround
Stop / Open/Close	HOLD Stop / Hold
Rec List / DVD Setup	LIST SMART Smart / List
Rec List / DVD Setup	OPT-TOOLS SETUP Setup / OPT /

Originalfernbedienung	Ersatzfernbedienung
<<	TUNE- << / Tune-
>>	TUNE+ >> / Tune+
Play / Pause	SLOW Play / Slow
Play / Pause	STEP-FREEZE Pause / Step / Freeze
Red / Goto	NETFLIX Red / Netflix / Search
Green / A-B	APP REPEAT Green / APP / Repeat
Yellow / Angle /	YouTube REPEAT A-B Yellow / YouTube / Repeat
Blue / Repeat	Prime Video RANDOM Blue / Prime Video / Random

