

ACER
PC/PROJECTOR
A-38030

Mandis Shop S.L.
Sant Cugat del Vallès - Barcelona
info@mandis.es

Layout Keys	Direct	Shift	Layout Keys	Direct	Shift
OFF	OFF				
ON	ON				
SRC SEARCH	Source				
AUTO MODE	eMode				
HIDE BLANK	Hide				
ASPECT RE-SYNC	Aspect	Resync			
MENU INFO	Menu				
EXIT LAMP	3D				
PICT FREEZE	Zoom	FREEZE			
MUTE FOCUS	Mute				
ZOOM/KEYSTONE+	Keystone Up				
ZOOM/KEYSTONE-	Keystone Down				
VOL/PAGE+	vol+	Page Up / SKIP NEXT			
VOL/PAGE-	Vol-	Page Down / S-Video			
/\	Up	PAGEUP			
/v	Down	PAGEDOWN			
<	Left				
>	Right				
OK	Menu				
1 POINTER	SKIP PREV	1 / SKIP PREV			
2 MOUSE LEFT B.	Play/Pause	2 / Play/Pause			
3 MOUSE RIGHT B.	SKIP NEXT	3 / STOP			
4 VGA1	Input Vga	4			
5 VGA2	STOP	5			
6 COMP	Input Component	6			
7 S-VIDEO	Input S-Video	7			
8 VIDEO	Input Video	8			
9 HDMI	Input HDMI/DVI	9			
0 LAN	Lan/WiFi	0			
USB	Input SD/Usb A				
PIP	Input Usb B				