

BENQ
PC/PROJECTOR
W703D

Mandis Shop S.L.
Sant Cugat del Vallès - Barcelona
info@mandis.es

Layout Keys	Direct	Shift	Layout Keys	Direct	Shift
OFF	POWER OFF	TIMER SETUP			
ON	POWER ON	TIMER ON / SHOW			
SRC SEARCH	SOURCE	SRS			
AUTO MODE	AUTO	SHARP			
HIDE BLANK	ECO BLANK	COLOR			
ASPECT RE-SYNC	ASPECT	COLOR TEMP			
MENU INFO	MENU / EXIT	TEST / QUICK INSTALL			
EXIT LAMP	MENU / EXIT	CONTRAST			
PICT FREEZE	FREEZE	BRIGHT			
MUTE FOCUS	MUTE	FINE TUNE			
ZOOM/KEYSTONE+	ZOOM+	UP / KEYSTONE UP			
ZOOM/KEYSTONE-	ZOOM□-	DOWN / KEYST.□DOWN			
VOL/PAGE+	VOL+	PAGE+			
VOL/PAGE-	VOL□-	PAGE□-			
∧	UP / KEYSTONE UP	MIC/VOL+			
∨	DOWN / KEYST.□DOWN	MIC/VOL□-			
<	LEFT / FAQ	NETWORK SETTING			
>	RIGHT / LOCK	CAPTURE			
OK	ENTER / MODE	3D			
1 POINTER	INPUT NETWORK	1 / ZOOM+			
2 MOUSE LEFT B.	TINT	2 / PAGE+			
3 MOUSE RIGHT B.	INPUT HDMI 2	3 / MIC/VOL+			
4 VGA1	INPUT COMPUTER	4 / ZOOM□-			
5 VGA2	INPUT COMPUTER	5 / PAGE□-			
6 COMP	INPUT COMPONENT	6 / MIC/VOL□-			
7 S-VIDEO	INPUT S-VIDEO	7 / FREEZE			
8 VIDEO	INPUT VIDEO	8 / ASPECT			
9 HDMI	INPUT HDMI	9			
0 LAN	USER2	0 / TEST / SMART ECO			
USB	USER1	INVERT			
PIP	USER3	PIP			