


THES
TV
THLTV3268D

Mandis Shop S.L.
Sant Cugat del Vallès (Barcelona)
info@mandis.es



Layout Keys	Direct	Shift	Layout Keys	Direct	Shift
POWER	Power	Sleep	V	Down	
MUTE	Mute		EXIT	Exit	
1	1		BACK	Back	
2	2		VOL+	Vol+	
3	3		VOL-	Vol-	
4	4		INFO	Info	TXT Index
5	5		FAV(F5)	Call	FAV
6	6		CH+	CH+	
7	7		CH-	CH-	
8	8		TEXT	TXT/MIX	TXT Hold
9	9		<?>	Audio	
0	0		...	Subtitle	
VOID	Mode		TV/RADIO	Tv/🎵 Browse	
MENU	Menu		CPI+	Timer/Nicam/A2	Scale
>PLAY			SOURCE	Reveal	
PAUSE			V-FORMAT	TXT Size	Picture
[STOP			WIDE	PIP	
RECORD					
<<					
>>					
<<					
>>					
RFD	Red/TXT R				
GRFN	Green/TXT G				
YELLOW	Yellow/TXT Y				
BLUE	Blue/TXT B				
MEDIA	Sys Menu				
EPG/GUIDE	-/--	EPG			
OK	Enter/List				
^	Up				
<	Left				
>	Right				