







































































Original		Replacement		Original		Replacement	
	Power		Power		Vol+		Vol+
	e/Energy/Savin		Sleep / Timer		FAV/Mark		Fav / Marker / PC
	AV Mode		Eject / Surround		P+		CH+ / Page+
	Input		AV / Input / RDS		Vol-		Vol-
	TV/RAD		TV/Radio /		Ratio		Picture / Format
	1		1		P-		CH- / Page-
	2		2		Mute		Mute / Dimmer
	3		3		Menu		Menu / Home
	4		4		Guide		Guide / EPG / -/-
	5		5		Q.Menu		D.Menu / Top
	6		6		Up		Up
	7		7		Left		Left
	8		8		OK		OK
	9		9		Right		Right
	List		Smart / List		Down		Down
	0		0		Back		Back / Return
	Q.View		Display / Media		Info		Info / Angle





Original		Replacement		Original		Replacement	
	Exit		Exit / Cancel / Clear				
	Red		Red / Netflix / Search				
	Green		Green / APP / Repeat				
	Yellow		Yellow / YouTube / Repeat				
	Blue		Blue / Prime Video / Random				
	Text		Text / Goto				
	T.Opt		Setup / OPT /				
	Subtitle		Subtitle / EQ				
	Stop		Stop / Hold				
	Play		Play / Slow				
	Pause		Pause / Step / Freeze				
	<<		<< / Tune-				
	>>		>> / Tune+				
	Simplink		Zoom / Size				
	AD		Audio / Lang I/II				

