







































































| Original | | Replacement | | Original | | Replacement | |
|---|----------|---|-----------------------------|---|----------|---|-----------------------|
|  | Power |  | Power |  | 7 |  | 7 |
|  | Screen |  | Picture / Format |  | 8 |  | 8 |
|  | Lang |  | Audio / Lang I/II |  | [≡]/Text |  | Text / Goto |
|  | Subtitle |  | Subtitle / EQ |  | 9 |  | 9 |
|  | www |  | Smart / List |  | 0 |  | 0 |
|  | Red/▲ |  | Red / Netflix / Search |  | Recall |  | Back / Return |
|  | Red/▲ |  | Shift + CH+ / |  | Up |  | Up |
|  | Green/▼ |  | Green / APP / Repeat |  | Menu |  | Menu / Home |
|  | Green/▼ |  | Shift + CH- / |  | Left |  | Left |
|  | Yellow |  | Yellow / YouTube / Repeat |  | Right |  | Right |
|  | Blue |  | Blue / Prime Video / Random |  | Return |  | Shift + Back / Return |
|  | 1 |  | 1 |  | Down |  | Down |
|  | 2 |  | 2 |  | OK |  | OK |
|  | 3 |  | 3 |  | Source |  | AV / Input / RDS |
|  | 4 |  | 4 |  | FAV |  | Fav / Marker / PC |
|  | 5 |  | 5 |  | Presets |  | Setup / OPT / |
|  | 6 |  | 6 |  | Sleep |  | Sleep / Timer |





| Original | | Replacement | |
|----------|------|--------------------|------------------|
| V+ | Vol+ | + VOL | Vol+ |
| P+ | P+ | + CH PAGE | CH+ / Page+ |
| INFO | Info | ANGLE INFO | Info / Angle |
| Mute | Mute | DIMMER MUTE | Mute / Dimmer |
| EPG | EPG | -- GUIDE EPG | Guide / EPG / -- |
| V- | Vol- | VOL - | Vol- |
| P- | P- | CH PAGE - | CH- / Page- |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Original | | Replacement | |
|----------|--|-------------|--|
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

