






































Original	Replacement	Original	Replacement
	Power		Yellow
	Play		Yellow
	Pause		List
	<<		Blue
	>>		Ch +
	I<<		Ch -
	>>I		AV
	Stop		Vol +
	Rec		Vol -
	Tv/TXT		Mute
	Cancel		Menu
	Hold		Exit
	Reveal		Smart
	Size		Up
	Red		Down
	Green		Right
	Subpage		Left
			Ok



