



Original	Replacement
Power	Power
Mute	Mute
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
FAV	+ Shift + Pre Ch
Recall	Pre Ch
Game	Media
Auto	Smart
Info	Info

Original	Replacement
Menu	Menu
EPG	Guide
Exit	Exit
Up / CH + / <<	Up
Down / CH - / >>	Down
Right / Vol +	Right
Left / Vol -	Left
OK	Ok
Up / CH + / <<	I<<
Down / CH - / >>	>>
Up / CH + / <<	Ch +
Down / CH - / >>	Ch -
Left / Vol -	Vol -
Right / Vol +	Vol +
Red / Zoom	Red
Green / Lan/Audio	Green
Yellow /	Yellow





Original	Replacement	Original	Replacement
	Blue / Text		Blue
	Red / Zoom		Eject
	Green / Lan/Audio		Dual
	Yellow /		Play
	Yellow /		Pause
	Blue / Text		Text
	<< / Tv/Radio		<<
	<< / Tv/Radio		TV/R
	>> / Subtitle		>>
	>> / Subtitle		Subt

