

































































































Original		Replacement		Original		Replacement	
	Power		Power		Green/Zoom		Green
	1		1		Yellow		Yellow
	2		2		Blue/[<>]		Blue
	3		3		[i]		Info
	4		4		Back		Back
	5		5		TXT		Text
	6		6		Menu		Menu
	7		7		TV-G		Guide
	8		8		Top Menu		Shift + Menu
	9		9		P+		Ch +
	0		0		P-		Ch -
	AV		AV		Vol+		Vol +
	?		Options		Vol-		Vol -
	[...]		Subt		Up		Up
	Audio		Dual		Down		Down
	Mute		Mute		Right		Right
	Red		Red		Left		Left























































Original		Replacement		Original	Replacement
	OK		Ok		
	I</Sound		I<<		
	>I/Picture		>>I		
	<<		<<		
	>>		>>		
	Rec/I>		Rec		
	Play		Play		
	Pause		Pause		
	Stop		Stop		
	List		List		
	FAV		Pre Ch		
	@		Media		
	3D		3D		
	CEC		TV/R		

































Original	Replacement	Original	Replacement
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	AV		AV
	?		Options
	[...]		Subt
	Audio		Dual
	Mute		Mute
	Red		Red
	Green/Zoom		Green
	Yellow		Yellow
	Blue/[<>]		Blue
	[i]		Info
	Back		Back
	Menu		Menu
	TXT		Text
	TV-G		Guide
	Top Menu		Shift + Menu
	P+		Ch +
	P-		Ch -
	Vol+		Vol +
	Vol-		Vol -
	Up		Up
	Down		Down
	Right		Right
	Left		Left




































































Original		Replacement		Original	Replacement
	OK		Ok		
	I</Sound		I<<		
	>I/Picture		>>I		
	<<		<<		
	>>		>>		
	Rec/I>		Rec		
	Play		Play		
	Pause		Pause		
	Stop		Stop		
	List		List		
	FAV		Pre Ch		
	@		Media		
	3D		3D		
	CEC		TV/R		





Original	Replacement	Original	Replacement
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	AV		AV
	?		Options
	[...]		Subt
	Audio		Dual
	Mute		Mute
	Red		Red
	Green/Zoom		Green
	Yellow		Yellow
	Blue/[<>]		Blue
	[i]		Info
	Back		Back
	TXT		Text
	Menu		Menu
	TV-G		Guide
	Top Menu		Shift + Menu
	P+		Ch +
	P-		Ch -
	Vol+		Vol +
	Vol-		Vol -
	Up		Up
	Down		Down
	Right		Right
	Left		Left





















































Original		Replacement		Original	Replacement
	OK		Ok		
	I</Sound		I<<		
	>I/Picture		>>I		
	<<		<<		
	>>		>>		
	Rec/I>		Rec		
	Play		Play		
	Pause		Pause		
	Stop		Stop		
	List		List		
	FAV		Pre Ch		
	@		Media		
	3D		3D		
	CEC		TV/R		





Original	Replacement	Original	Replacement
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	AV		AV
	?		Options
	[...]		Subt
	Audio		Dual
	Mute		Mute
	Red		Red
	Green/Zoom		Green
	Yellow		Yellow
	Blue/[<>]		Blue
	[i]		Info
	Back		Back
	Menu		Menu
	TXT		Text
	TV-G		Guide
	Top Menu		Shift + Menu
	P+		Ch +
	P-		Ch -
	Vol+		Vol +
	Vol-		Vol -
	Up		Up
	Down		Down
	Right		Right
	Left		Left





Original		Replacement		Original		Replacement	
	OK		Ok				
	I</Sound		I<<				
	>I/Picture		>>I				
	<<		<<				
	>>		>>				
	Rec/I>		Rec				
	Play		Play				
	Pause		Pause				
	Stop		Stop				
	List		List				
	FAV		Pre Ch				
	@		Media				
	3D		3D				
	CEC		TV/R				

