













































































Original	Replacement	Original	Replacement
	Power		Power
	Source		SRC
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Guide		-/-- / EPG
	Infos		INFO
	Mute		MUTE
	Vol +		VOL +
	Vol -		VOL -
	Format		V-FOR
	Prog +		CH +
	Prog -		CH -
	Red		Red (A)
	Green		Green (B)
	Yellow		Yellow (C)
	Blue		Blue (D)
	Menu		MENU
	Media		MEDIA
	Up		UP
	Down		DOWN
	Right		RIGHT
	Left		LEFT
	OK		OK
	Back		BACK
	Exit		EXIT
	AD		Audio





	Original	Replacement		Original	Replacement
	Subtitle	 Subt.			
	Text	 TEXT			
	Radio	 TV/R			
	I<<	 First			
	<<	 Rewind			
	>>	 Fast Forward			
	>>I	 Last			
	Rec	 Rec			
	Stop	 Stop			
	Play	 Play			
	Pause	 Pause			

