

































Original	Replacement
 Power	 Power
 Mute	 Mute
 Source	 AV
 MyEPG	 Pre Ch
 V-Format	 Format
 Wide	 3D
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Text	 Text

Original	Replacement
 Menu	 Menu
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 List	 List
 Guide	 Guide
 Exit	 Exit
 Back	 Back
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 Vol+	 Vol +
 Vol-	 Vol -
 i	 Info





Original	Replacement	Original	Replacement
	OPT+		Options
	P+		Ch +
	P-		Ch -
	m@p		Media
	Audio		Dual
	SUB		Subt
	TV/Radio		TV/R
	Play		Play
	Pause		Pause
	Rec		Rec
	Stop		Stop
	<<		<<
	>>		>>
	I<<		I<<
	>>I		>>I

