












































| Original | Replacement | Original | Replacement |
|-------------|--|------------|---|
| On/Off |  Power | OK Enter |  Ok |
| Mute |  Mute | Menu Right |  Right |
| Update |  Media | Menu Off |  Exit |
| Reveal |  Smart | Menu Down |  Down |
| Txt Stop |  Stop | Back |  Back |
| Info |  Info | Volume+ |  Vol + |
| Subt.List |  Subt | Chan.Up |  Ch + |
| Sleep Timer |  Sleep | Volume- |  Vol - |
| Return TV |  TV/R | Menu audio |  Dual |
| Menu video |  D. Menu | Chan.Down |  Ch - |
| Text |  Text | 1 |  1 |
| Txt Expand |  Eject | 2 |  2 |
| TV/AV |  AV | 3 |  3 |
| Menu |  Menu | 4 |  4 |
| Menu Up |  Up | 5 |  5 |
| Display |  Shift + Info | 6 |  6 |
| Menu Left |  Left | 7 |  7 |



| Original | Replacement | Original | Replacement |
|---------------|--|----------|-------------|
| 8 |  8 | | |
| 9 |  9 | | |
| Guide -/-- 1. |  GUIDE | | |
| 0/10 |  0 | | |
| 2.Fav P/C 2. |  PRE-CH | | |
| Red |  A | | |
| Green |  B | | |
| Yellow |  C | | |
| Blue |  D | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

