














| Original | Replacement |
|---|--|
|  Power |  Power |
|  Sleep |  Sleep |
|  Display |  Info |
|  Mute |  Mute |
|  NICAM |  Dual |
|  PC |  AV |
|  Auto AD |  Shift + Subt |
|  TV / AV |  TV/R |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |

| Original | Replacement |
|--|--|
|  0 |  0 |
|  PSM |  Format |
|  SSM |  Shift + Dual |
|  OK |  Ok |
|  Q.View |  D. Menu |
|  Up / P + |  Up |
|  Up / P + |  Ch + |
|  Down / P - |  Down |
|  Down / P - |  Ch - |
|  Right / V + |  Vol + |
|  Right / V + |  Right |
|  Left / V - |  Vol - |
|  Left / V - |  Left |
|  Menu |  Menu |
|  Index |  Smart |
|  Subtitle |  Subt |
|  Mix |  Media |



