


























































Original		Replacement		Original		Replacement	
	Power		Power		Info		Info
	Mute		Mute		Up		Up
	1		1		Right		Right
	2		2		Down		Down
	3		3		Left		Left
	4		4		OK		Ok
	5		5		Exit		Exit
	6		6		Menu		Menu
	7		7		EPG		Guide
	8		8		Vol +		Vol +
	9		9		Vol -		Vol -
	0		0		CH + / Page +		Ch +
	Text		Text		CH - / Page -		Ch -
	Audio		Dual		Red		Red
	Help		D. Menu		Green		Green
	Back		Back		Yellow		Yellow
	Subtitle		Subt		Blue		Blue



