



| Original | Replacement | Original | Replacement |
|---|-------------|---|----------------------------|
|  | Power |  | Power |
|  | TV / SAT |  | Shift + TV/Radio / Program |
|  | Pause |  | Pause / Step / Freeze |
|  | Sleep |  | Sleep / Timer |
|  | 1 |  | 1 |
|  | 2 |  | 2 |
|  | 3 |  | 3 |
|  | 4 |  | 4 |
|  | 5 |  | 5 |
|  | 6 |  | 6 |
|  | 7 |  | 7 |
|  | 8 |  | 8 |
|  | 9 |  | 9 |
|  | RCL |  | Setup / OPT / |
|  | 0 |  | 0 |
|  | EPG |  | Guide / EPG / -/-- |
|  | Menu |  | Menu / Home |
|  | Up |  | Up |
|  | Mode |  | D.Menu / Top |
|  | Left |  | Left |
|  | OK |  | OK |
|  | Right |  | Right |
|  | Exit |  | Exit / Cancel / Clear |
|  | Down |  | Down |
|  | TV / Rad |  | TV/Radio / |
|  | Color |  | Picture / Format |
|  | i |  | Info / Angle |
|  | Help |  | Shift + Info / Angle |
|  | Mute |  | Mute / Dimmer |
|  | Audio |  | Audio / Lang I/II |
|  | Subtitle |  | Subtitle / EQ |
|  | Red |  | Red / Netflix / Search |
|  | Green |  | Green / APP / Repeat |
|  | Yellow |  | Yellow / YouTube / Repeat |



