







































































Original	Replacement	Original	Replacement
	Power		Power
	i+		Info / Angle
	Sleep		Sleep / Timer
	Rec List		Smart / List
	Media Player		Display / Media
	Audio I/II/I+II		Audio / Lang I/II
	Mute		Mute / Dimmer
	1		1
	2		2
	3		3
	Vol +		Vol+
	4		4
	5		5
	6		6
	Vol -		Vol-
	7		7
	8		8
	9		9
	P +		CH+ / Page+
	Recall		Back / Return
	0		0
	Input		AV / Input / RDS
	P -		CH- / Page-
	DTV		D.Menu / Top
	Aspect		Picture / Format
	PC		Shift + Fav / Marker / PC
	Radio		TV/Radio /
	Play / Pause		Play / Slow
	Play / Pause		Pause / Step / Freeze
	Up / >>I		Up
	Up / >>I		>>I / Preset+
	Menu		Menu / Home
	Left / <<		<< / Tune-
	Left / <<		Left





Original		Replacement	
	OK		OK
	Right / >>		Right
	Right / >>		>> / Tune+
	End		Exit / Cancel / Clear
	Down / <<		Down
	Down / <<		<< / Preset-
	Red		Rec / Rec Mode
	Green		Red / Netflix / Search
	Yellow		Green / APP / Repeat
	Blue		Yellow / YouTube / Repeat
	Blue		Blue / Prime Video / Random
	EPG		Guide / EPG / -/--
	Text		Text / Goto
	Reveal		Setup / OPT /
	Subtitle		Subtitle / EQ
	FAV		Fav / Marker / PC
	Hold		Stop / Hold

Original		Replacement	
	Timer		Shift + Sleep / Timer
	Size		Zoom / Size

