




























































| Original | Replacement |
|--|--|
|  Power |  Power |
|  Mute |  Mute |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  0 |  0 |
|  --/10+ |  Shift + Guide |
|  Recall |  Back |
|  Subtitle |  Subt |
|  P.Mode |  Shift + Format |
|  S.Mode |  Dual |

| Original | Replacement |
|--|--|
|  MTS |  Media |
|  Sleep |  Sleep |
|  Source |  AV |
|  CH+ |  Ch + |
|  CH- |  Ch - |
|  Vol+ |  Vol + |
|  Vol- |  Vol - |
|  Info |  Info |
|  Freeze |  Red |
|  CH.List |  List |
|  Auto |  Yellow |
|  Aspect |  Format |
|  Up |  Up |
|  Down |  Down |
|  OK |  Ok |
|  Right |  Right |
|  Left |  Left |





| Original | | Replacement | | Original | | Replacement | |
|---|------------------|---|--------------|---|----|---|----|
|  | Menu |  | Menu |  | << |  | << |
|  | Exit |  | Exit |  | >> |  | >> |
|  | CC |  | Smart | | | | |
|  | Eject / V-Chip |  | Eject | | | | |
|  | Play/Pause / FAV |  | Play | | | | |
|  | Play/Pause / FAV |  | Pre Ch | | | | |
|  | Stop/ADD/Erase |  | Stop | | | | |
|  | Title |  | Options | | | | |
|  | Setup/EPG |  | Guide | | | | |
|  | Audio |  | Shift + Dual | | | | |
|  | Goto |  | TV/R | | | | |
|  | A-B |  | Shift + Text | | | | |
|  | Menu (lower) |  | D. Menu | | | | |
|  | Slow |  | Pause | | | | |
|  | Repeat |  | Text | | | | |
|  | << |  | << | | | | |
|  | >> |  | >> | | | | |

