




















































Original	Replacement	Original	Replacement
 Power DVR	 Power	 Tivo	 Smart / List
 Play	 Play / Slow	 Prg+	 CH+ / Page+
 Pause	 Pause / Step / Freeze	 Guia	 Display / Media
 Rec	 Rec / Rec Mode	 Prg-	 CH- / Page-
 <<	 << / Tune-	 1	 1
 >>	 >> / Tune+	 2	 2
 Idiomas	 Audio / Lang I/II	 3	 3
 Videoclub	 Picture / Format	 4	 4
 Zoom	 Zoom / Size	 5	 5
 Ver TV/Cambiar	 TV/Radio /	 6	 6
 Up	 Up	 7	 7
 Info	 Info / Angle	 8	 8
 Left	 Left	 9	 9
 OK	 OK	 C	 Guide / EPG / -/-
 Right	 Right	 0	 0
 Down	 Down	 Red	 Red / Netflix / Search
 Back	 Back / Return	 Green	 Green / APP / Repeat



