





































































Original	Replacement	Original	Replacement
 Power	 Power	 Analog	 Shift + TV/R
 1	 1	 Digital	 TV/R
 2	 2	 Return	 Back
 3	 3	 Exit	 Exit
 4	 4	 Up	 Up
 5	 5	 Left / Z -	 Left
 6	 6	 Right / Z +	 Right
 7	 7	 Down	 Down
 8	 8	 OK	 Ok
 9	 9	 Menu	 Menu
 0	 0	 Presets	 Smart
 AV	 AV	 List	 List
 Mute	 Mute	 Info	 Info
 PR +	 Ch +	 Guide	 Guide
 PR -	 Ch -	 Red	 Red
 Vol +	 Vol +	 Green	 Green
 Vol -	 Vol -	 Yellow	 Yellow



