


































































Original	Replacement	Original	Replacement
 Power	 Power	 Language	 Dual
 Mute	 Mute	 Favourite	 Pre Ch
 DVB / Analog	 TV/R	 Cancel / Exit	 Exit
 Multi Media	 Media	 Menu	 Menu
 AV	 AV	 Aspect	 Format
 Normal	 Smart	 Audio I / II	 Shift + Dual
 Vol +	 Vol +	 Recall	 Back
 Vol -	 Vol -	 S.Effect	 Options
 PR/Page +	 Ch +	 1	 1
 PR/Page -	 Ch -	 2	 2
 Up	 Up	 3	 3
 Left	 Left	 4	 4
 OK / Select	 Ok	 5	 5
 Right	 Right	 6	 6
 Down	 Down	 7	 7
 Guide	 Guide	 8	 8
 Subtitle	 Subt	 9	 9





Original	Replacement
0	0
Still	Pause
Sleep	Sleep
Red	Red
Green	Green
Yellow	Yellow
Blue	Blue
Text	Text
Reveal	List
T.Cancel	Shift + Exit
Size	Eject
S-Code	Shift + Subt
Hold	Stop
Mix	Shift + Text
Index	Info
P.Mode	Shift + Format
P.Still / P.Size	Shift + Pause

Original	Replacement
P.Swap	Shift + Back
P.Input	Shift + AV
P.PR +	Shift + Ch +
P.PR -	Shift + Ch -

