







































































| Original | Replacement | Original | Replacement |
|--|---|--|--|
|  Power |  Power |  Vol+ |  Vol + |
|  Mute |  Mute |  Vol- |  Vol - |
|  Sleep |  Sleep |  Left |  Left |
|  Nicam/A2 |  Dual |  Enter |  Ok |
|  Still |  Pause |  1 |  1 |
|  16:9 |  Format |  2 |  2 |
|  NR. |  Options |  3 |  3 |
|  Surround |  List |  4 |  4 |
|  Picture |  Shift + Format |  5 |  5 |
|  Tv/Av |  AV |  6 |  6 |
|  Display |  Info |  7 |  7 |
|  Sound |  Shift + Dual |  8 |  8 |
|  Up |  Up |  9 |  9 |
|  CH+ |  Ch + |  0 |  0 |
|  CH- |  Ch - |  -/-- |  Guide |
|  Down |  Down |  Recall |  Pre Ch |
|  Right |  Right |  Red |  Red |



