
















Original	Replacement
 Power	 Power
 Mute	 Mute
 Rec	 Rec
 Goto	 Smart
 Aspect	 3D
 V.Format	 Format
 <<	 <<
 >>	 >>
 Play	 Play
 Pause	 Pause
 Stop	 Stop
 Tv/Radio	 TV/R
 Audio	 Dual
 Dev	 Options
 Recall	 Back
 Red/TTX	 Red
 Green/SUB.T	 Green

Original	Replacement
 Yellow/Zoom	 Yellow
 Blue/Option	 Blue
 Info	 Info
 FAV	 Pre Ch
 Menu	 Menu
 Exit	 Exit
 Up/CH+	 Up
 Down/CH-	 Down
 Right/Vol+	 Right
 Left/Vol-	 Left
 OK	 Ok
 Vol+	 Vol +
 Vol-	 Vol -
 SAT	 Media
 EPG	 Guide
 Page+	 Ch +
 Page-	 Ch -





Original		Replacement	
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
FIND	Find	TIMER AV	AV
MP	MP	DISC NAV LIST	List

Original		Replacement	

