








































































































Original	Replacement
 Power	 Power
 Mute	 Mute / Dimmer
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Vol+	 Vol+
 Vol-	 Vol-
 TV/R	 TV/Radio /
 Page+	 CH+ / Page+
 Page-	 CH- / Page-



































Original	Replacement
 IPTV	 Smart / List
 VOD	 Display / Media
 Info	 Info / Angle
 Menu	 Menu / Home
 Exit	 Exit / Cancel / Clear
 Recall	 Back / Return
 Up	 Up
 Down	 Down
 OK	 OK
 Right	 Right
 Left	 Left
 Red/YouTube	 Red / Netflix / Search
 Red/YouTube	 Shift + Yellow / YouTube / Repeat A-B
 Green	 Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat
 Blue/Quran	 Blue / Prime Video / Random
 TTX/CC	 Text / Goto







Original	Replacement	Original	Replacement
Power	 Power	Audio	 Audio / Lang I/II
Mute	 Mute / Dimmer	EPG	 Guide / EPG / -/-
<<	 << / Tune-	i	 Info / Angle
Green/VOD	 Green / APP / Repeat	Menu	 Menu / Home
Yellow/YouTube	 Yellow / YouTube / Repeat	Exit	 Exit / Cancel / Clear
Blue/Quran	 Blue / Prime Video / Random	FAV	 Fav / Marker / PC
Red/IPTV	 Red / Netflix / Search	Rec	 Rec / Rec Mode
>>	 >> / Tune+	Up	 Up
I<<	 I<< / Preset-	OK	 OK
>>I	 >>I / Preset+	Down	 Down
Play	 Play / Slow	Right	 Right
Pause	 Pause / Step / Freeze	Left	 Left
Stop	 Stop / Hold	Vol+	 Vol+
SAT	 Shift + 9	Vol-	 Vol-
Media	 Display / Media	Page+	 CH+ / Page+
Timer	 Sleep / Timer	Page-	 CH- / Page-
Recall	 Back / Return	1	 1

Original	Replacement	Original	Replacement
Power	 Power	Audio	 Audio / Lang I/II
Mute	 Mute / Dimmer	EPG	 Guide / EPG / -/-
<<	 << / Tune-	i	 Info / Angle
Green/VOD	 Green / APP / Repeat	Menu	 Menu / Home
Yellow/YouTube	 Yellow / YouTube / Repeat	Exit	 Exit / Cancel / Clear
Blue/Quran	 Blue / Prime Video / Random	FAV	 Fav / Marker / PC
Red/IPTV	 Red / Netflix / Search	Rec	 Rec / Rec Mode
>>	 >> / Tune+	Up	 Up
I<<	 I<< / Preset-	OK	 OK
>>I	 >>I / Preset+	Down	 Down
Play	 Play / Slow	Right	 Right
Pause	 Pause / Step / Freeze	Left	 Left
Stop	 Stop / Hold	Vol+	 Vol+
SAT	 Shift + 9	Vol-	 Vol-
Media	 Display / Media	Page+	 CH+ / Page+
Timer	 Sleep / Timer	Page-	 CH- / Page-
Recall	 Back / Return	1	 1



