








































































Original		Replacement		Original		Replacement	
	Power		Power		Exit		Exit
	Mute		Mute		Up		Up
	1		1		Left		Left
	2		2		OK		Ok
	3		3		Right		Right
	4		4		Down		Down
	5		5		Vol+		Vol +
	6		6		Vol-		Vol -
	7		7		CH-		Ch -
	8		8		CH+		Ch +
	9		9		Red		Red
	0		0		Green		Green
	TV / R		TV/R		Yellow		Yellow
	AV		AV		Blue		Blue
	Menu		Menu		APP		Media
	Text		Text		SUB		Subt
	Back		Back		List		List





Original		Replacement		Original		Replacement	
	i		Info				
	Audio		Dual				
	EPG		Guide				

