



Original	Replacement	Original	Replacement
STB/DVR	3	Vol-	Vol -
Power Receiver	Power	Home	Smart
Display	Info	CH+	Ch +
BD / DVD	1	CH-	Ch -
CBL / SAT	2	SP Layout	D. Menu
GAME	4	Menu	Menu
PC	5	Up	Up
AUX	6	Left	Left
TUNER	AV	Enter	Ok
TUNER	7	Right	Right
TV / CD	8	Down	Down
PHONO	9	Setup	Options
USB	0	Return	Back
USB	Media	I<<	I<<
NET	Guide	>>I	>>I
Muting	Mute	<<	<<
Vol+	Vol +	Play	Play

Original	Replacement	Original	Replacement
STB/DVR	3	Vol-	Vol -
Power Receiver	Power	Home	Smart
Display	Info	CH+	Ch +
BD / DVD	1	CH-	Ch -
CBL / SAT	2	SP Layout	D. Menu
GAME	4	Menu	Menu
PC	5	Up	Up
AUX	6	Left	Left
TUNER	AV	Enter	Ok
TUNER	7	Right	Right
TV / CD	8	Down	Down
PHONO	9	Setup	Options
USB	0	Return	Back
USB	Media	I<<	I<<
NET	Guide	>>I	>>I
Muting	Mute	<<	<<
Vol+	Vol +	Play	Play




















Original	Replacement
>>	>>
Pause / Play Rev.	Pause
Stop	Stop
Movie / TV	Red
Music	Green
Game	Yellow
Thx	Blue
Dimmer	Dual
D.TUN	TV/R
Sleep	Sleep
1	+ Shift + 1
2	+ Shift + 2
3	+ Shift + 3
4	+ Shift + 4
5	+ Shift + 5
6	+ Shift + 6
7	+ Shift + 7

Original	Replacement
8	+ Shift + 8
9	+ Shift + 9
0	+ Shift + 0





Original	Replacement	Original	Replacement
 Power Receiver	 Power	 Home	 Smart
 BD / DVD	 1	 CH+ / Album+	 Ch +
 STB / DVR	 3	 CH- / Album-	 Ch -
 CBL / SAT	 2	 Top Menu	 D. Menu
 GAME	 4	 Menu	 Menu
 PC	 5	 Up	 Up
 AUX	 6	 Page- / Playlist-	 Left
 TUNER	 7	 Enter	 Ok
 TUNER	 AV	 Page+ / Playlist+	 Right
 TV / CD	 8	 Down	 Down
 PHONO	 9	 Setup	 Options
 NET	 Guide	 Return	 Back
 USB	 0	 I<<	 I<<
 USB	 Media	 >>I	 >>I
 Muting	 Mute	 <<	 <<
 Vol+	 Vol +	 Play	 Play
Vol-	Vol -	>>	>>









































































Original	Replacement
Pause / Play Rev.	Pause
Stop	Stop
Search	TV/R
Search	Red
Repeat	Green
Repeat	Text
Random	Yellow
Mode	Blue
Mode	SHIFT + Play
1	SHIFT + 1
2	SHIFT + 2
3	SHIFT + 3
4	SHIFT + 4
5	SHIFT + 5
6	SHIFT + 6
7	SHIFT + 7
8	SHIFT + 8

Original	Replacement
9	SHIFT + 9
0	SHIFT + 0
--/--- +10	SHIFT + Guide
Sleep	Sleep
Display	Info
CLR	Exit







Original	Replacement	Original	Replacement
 Power Receiver Zone 2	 Power	 << Zone 2	 <<
 Vol+ Zone 2	 Vol +	 Pause Zone 2	 Pause
 Vol- Zone 2	 Vol -	 Stop Zone 2	 Stop
 CH Disc/Album+ Zone 2	 Ch +	 Movie Tv/Search Zone 2	 Red
 CH Disc/Album- Zone 2	 Ch -	 Music/Repeat	 Green
 Up Zone 2	 Up	 Game/Random	 Yellow
 Enter Zone 2	 Ok	 Stereo/Play Mode Zone 2	 Blue
 Down Zone 2	 Down	 1 Zone 2	 1
 Right Zone 2	 Right	 2 Zone 2	 2
 Left Zone 2	 Left	 3 Zone 2	 3
 Return Zone 2	 Back	 4 Zone 2	 4
 Setup Zone 2	 Smart	 5 Zone 2	 5
 Audio Zone 2	 Media	 6 Zone 2	 6
 I<< Zone 2	 I<<	 7 Zone 2	 7
 >>I Zone 2	 >>I	 8 Zone 2	 8
 Play Zone 2	 Play	 9 Zone 2	 9
 >> Zone 2	 >>	 0/11 Zone 2	 0





	Original	Replacement	Original	Replacement
	+10/--/--10/D.Tun/ Dimmer Zone 2			Guide
	CLR/Sleep/12			Pre Ch

