


















































Original		Replacement		Original		Replacement	
	Power		Power		Blue		Blue
			Eject		P.Mode		Shift + Format
	1		1		S.Mode		Shift + Dual
	2		2		Mute		Mute
	3		3		TXT		Text
	4		4		Aspect		Format
	5		5		Audio		Shift + 3D
	6		6		Display		Info
	7		7		Sleep		Sleep
	8		8		Up / PR +		Up
	9		9		Up / PR +		Ch +
	0		0		Down / PR -		Down
	-/--		Shift + Guide		Down / PR -		Ch -
	Recall		Back		Right / Vol +		Right
	Red		Red		Right / Vol +		Vol +
	Green		Green		Left / Vol -		Left
	Yellow		Yellow		Left / Vol -		Vol -





Original		Replacement		Original	Replacement
	Enter		Ok		
	Source		AV		
	Menu		Menu		
	Hold		Stop		
	Mix		Shift + Text		
	Subpage		Shift + Subt		
	Size		Shift + Eject		
	Index		3D		
	Reveal		Media		
	DTV/Radio		TV/R		
	List		List		
	EPG		Guide		
	FAV		Pre Ch		
	Page Down		I<<		
	Page Up		>>I		
	Still		Pause		
	Subtitle		Subt		

