







































































Original	Replacement	Original	Replacement
 ON/OFF	 Power	 Vol-	 Vol -
 Freeview Play	 Options	 Mute	 Mute
 1	 1	 CH+	 Ch +
 2	 2	 CH-	 Ch -
 3	 3	 Menu	 Menu
 4	 4	 Exit	 Exit
 5	 5	 Back	 Back
 6	 6	 FAV	 Pre Ch
 7	 7	 Up	 Up
 8	 8	 Down	 Down
 9	 9	 Right	 Right
 0	 0	 Left	 Left
 Tv Guide	 Guide	 OK	 Ok
 Picture	 Format	 Info	 Info
 Sound	 Dual	 Text	 Text
 Source	 AV	 Subtitle	 Subt
 Vol+	 Vol +	 TV	 TV/R





Original	Replacement	Original	Replacement
You Tube	Media		
Netflix	Smart		
APPs	Shift + Media		
Rec/DVD Menu	Rec		
I<<	I<<		
>>	>>		
Stop	Stop		
Rec List/DVD	D. Menu		
<<	<<		
>>	>>		
Play	Play		
Pause	Pause		
Red/Goto	Red		
Green/A-B	Green		
Yellow/Angle	Yellow		
Blue/Repeat	Blue		

Original	Replacement

