









































































| Original | | Replacement | | Original | | Replacement | |
|---|-----------|---|--------------------|---|--------|---|-----------------------|
|  | Mute |  | Mute / Dimmer |  | Up |  | Up |
|  | Power |  | Power |  | Left |  | Left |
|  | 1 |  | 1 |  | OK |  | OK |
|  | 2 |  | 2 |  | Right |  | Right |
|  | 3 |  | 3 |  | Down |  | Down |
|  | 4 |  | 4 |  | Exit |  | Exit / Cancel / Clear |
|  | 5 |  | 5 |  | Recall |  | Back / Return |
|  | 6 |  | 6 |  | Menu |  | Menu / Home |
|  | 7 |  | 7 |  | CH+ |  | CH+ / Page+ |
|  | 8 |  | 8 |  | Text |  | Text / Goto |
|  | 9 |  | 9 |  | Option |  | Setup / OPT / |
|  | EPG |  | Guide / EPG / -/-- |  | Vol+ |  | Vol+ |
|  | 0 |  | 0 |  | CH- |  | CH- / Page- |
|  | List |  | Smart / List |  | F1 |  | Shift + 1 |
|  | Mode |  | D.Menu / Top |  | F2 |  | Shift + 2 |
|  | i |  | Info / Angle |  | Vol- |  | Vol- |
|  | TV/R Live |  | TV/Radio / |  | Rec |  | Rec / Rec Mode |





| Original | Replacement | Original | Replacement |
|---|---|----------|-------------|
|  Play |  Play / Slow | | |
|  Archive |  Display / Media | | |
|  << |  << / Tune- | | |
|  Stop |  Stop / Hold | | |
|  Pause |  Pause / Step / Freeze | | |
|  >> |  >> / Tune+ | | |
|  Red |  Red / Netflix / Search | | |
|  Green |  Green / APP / Repeat | | |
|  Yellow |  Yellow / YouTube / Repeat | | |
|  Blue |  Blue / Prime Video / Random | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Original | Replacement |
|----------|-------------|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

