





















	Original	Replacement	Original	Replacement
	Phono	 1		
	CD	 2		
	Tuner	 3		
	Aux	 4		
	Tape1	 5		
	Tape2	 6		
	Vol+	 Vol +		
	Vol-	 Vol -		
	Mute	 Mute		

