






















































| Original | Replacement | |
|--------------|---|---------------|
| On/Off |  | Power |
| Audio Off |  | Mute |
| Slow Down |  | Ch - |
| Slow Up |  | Ch + |
| Pause |  | Pause |
| Auto/Track |  | Smart |
| Stop |  | Stop |
| Subt. |  | Subt |
| Title |  | List |
| Rep/A-B |  | TV/R |
| Pepeat/1/All |  | Text |
| Zoom |  | Shift + Eject |
| DVD/TV |  | AV |
| Menu |  | Menu |
| Menu Up |  | Up |
| Display |  | Info |
| Return |  | Back |














| Original | Replacement | |
|------------|---|---------|
| Menu Left |  | Left |
| OK Enter |  | Ok |
| Progr. |  | Sleep |
| Next |  | >> |
| Menu Right |  | Right |
| Prev. |  | << |
| Menu Down |  | Down |
| Volume+ |  | Vol + |
| Volume- |  | Vol - |
| Top Menu |  | D. Menu |
| 1 |  | 1 |
| 2 |  | 2 |
| 3 |  | 3 |
| 4 |  | 4 |
| 5 |  | 5 |
| Store |  | Red |
| 6 |  | 6 |




















| Original | Replacement | |
|-------------|---|---------|
| Digest |  | Green |
| 7 |  | 7 |
| Open/Close |  | Eject |
| 8 |  | 8 |
| 9 |  | 9 |
| Clear/00:00 |  | Exit |
| +10 |  | Guide |
| Record |  | Rec |
| Auto Scan |  | Media |
| Rewind |  | << |
| Play |  | Play |
| F.Forward |  | >> |
| Setup |  | Options |
| Audio |  | Dual |
| 3D |  | 3D |
| 0 |  | 0 |
| C/CH |  | Pre Ch |

















| Original | Replacement | |
|----------|---|--------------|
| Angle |  | Format |
| Np |  +  | Shift + Subt |
| Info |  +  | Shift + Info |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |





































| Original | Replacement | |
|--------------|---|---------------|
| On/Off |  | Power |
| Audio Off |  | Mute |
| Stop |  | Stop |
| Pause |  | Pause |
| Slow Up |  | Ch + |
| Slow Down |  | Ch - |
| Subt. |  | Subt |
| Auto/Track |  | Sleep |
| Rep/A-B |  | TV/R |
| Zoom |  +  | Shift + Eject |
| Title |  | List |
| Pepeat/1/All |  | Text |
| DVD/TV |  | AV |
| Menu |  | Menu |
| Menu Up |  | Up |
| Display |  | Info |
| Menu Left |  | Left |

| Original | Replacement | |
|------------|---|---------|
| OK Enter |  | Ok |
| Menu Right |  | Right |
| Return |  | Exit |
| Menu Down |  | Down |
| Progr. |  | Back |
| Volume+ |  | Vol + |
| Top Menu |  | D. Menu |
| Next |  | >>I |
| Volume- |  | Vol - |
| 1 |  | 1 |
| 2 |  | 2 |
| 3 |  | 3 |
| Prev. |  | I<< |
| 4 |  | 4 |
| 5 |  | 5 |
| 6 |  | 6 |
| 7 |  | 7 |








| Original | Replacement | Original | Replacement |
|------------|--|----------|-------------|
| 8 |  8 | | |
| Video |  Smart | | |
| 9 |  9 | | |
| +10 |  Guide | | |
| 0 |  0 | | |
| C/CH |  Pre Ch | | |
| Rewind |  << | | |
| Random |  Media | | |
| Angle |  Format | | |
| R/L |  +  Shift + Info | | |
| Play |  Play | | |
| Record |  Rec | | |
| F.Forward |  >> | | |
| 3D |  3D | | |
| Open/Close |  Eject | | |
| Audio |  Dual | | |
| | | | |



| Original | Replacement | Original | Replacement |
|--------------|---|------------|---|
| On/Off |  Power | OK Enter |  Ok |
| Audio Off |  Mute | Menu Right |  Right |
| Slow Down |  Ch - | Return |  Back |
| Slow Up |  Ch + | Menu Down |  Down |
| Auto/Track |  Smart | Next |  >> |
| Stop |  Stop | Progr. |  Sleep |
| Subt. |  Subt | Volume+ |  Vol + |
| Pause |  Pause | Top Menu |  D. Menu |
| Zoom |  Shift + Eject | Volume- |  Vol - |
| Title |  List | Prev. |  << |
| Rep/A-B |  TV/R | 1 |  1 |
| Pepeat/1/All |  Text | 2 |  2 |
| DVD/TV |  AV | 3 |  3 |
| Menu |  Menu | 4 |  4 |
| Menu Up |  Up | 5 |  5 |
| Display |  Info | 6 |  6 |
| Menu Left |  Left | 7 |  7 |



| Original | Replacement | Original | Replacement |
|--------------|---|---------------|-------------|
| 8 |  | 8 | |
| Open/Close |  | Eject | |
| Mode |  | Media | |
| 9 |  | 9 | |
| Setup |  | Options | |
| +10 |  | Guide | |
| 3D |  | 3D | |
| 0 |  | 0 | |
| C/CH |  | Pre Ch | |
| Play/Back |  +  | Shift + Left | |
| Resume |  +  | Shift + Play | |
| Play |  | Play | |
| Karaoke/Step |  +  | Shift + Pause | |
| Np |  +  | Shift + Subt | |
| Record |  | Rec | |
| F.Forward |  | >> | |
| Rewind |  | << | |

| Original | Replacement | Original | Replacement |
|----------|---|--------------|-------------|
| Store |  +  | Shift + Down | |
| Angle |  | Format | |
| Lang |  | Dual | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

