






















































Original		Replacement		Original		Replacement	
	Power		Power		Subpage		Media
	Mute		Mute		Pre-CH		Pre Ch
	Display		Info		PC		Smart
	CH+		Ch +		Tv/Video		TV/R
	CH-		Ch -		Sleep		Sleep
	Vol+		Vol +		Sound		Dual
	Vol-		Vol -		Up		Up
	1		1		Down		Down
	2		2		Right		Right
	3		3		Left		Left
	4		4		Menu		Menu
	5		5		Mix		AV
	6		6		Teletext		Text
	7		7		Text Size		Format
	8		8		Red		Red
	9		9		Green		Green
	0		0		Yellow		Yellow





	Original	Replacement	Original	Replacement
	Blue	 D		Blue
	Index	 DISC NAV LIST		List
	Subtitle	 AD SUBT		Subt
	Hold	 E-MANUAL D.MENU		D. Menu
	Reveal	 SETTINGS OPT		Options
	PIP/POP	 ECO 3D		3D
	PIP Swap	 RETURN BACK		Back
	PIP Size	 ZOOM ▲		Eject

