



































































Original	Replacement	Original	Replacement
 On/Standby	 Power	 Sleep	 Sleep
 CD	 Red	 Clock	 Smart
 Video/AUX	 Green	 Clear	 Exit
 Tuner	 Yellow	 Timer	 AV
 Band	 Blue	 Random/Repeat	 Text
 Play	 Play	 Memory	 Menu
 Pause	 Pause	 Dimmer	 Media
 Stop	 Stop	 Surround	 Dual
 >>	 >>	 Bass Up	 Ch +
 <<	 <<	 Bass Down	 Ch -
 Vol+	 Vol +	 Treble Down	 Left
 Vol-	 Vol -	 Treble Up	 Right
 Preset Up	 Up	 Display	 Info
 Preset Down	 Down	 EON	 Subt
 >>/Tuner Up	 >>	 PTY-TI	 TV/R
 <</Tuner Down	 <<	 ASPM	 3D
Open/Close	Eject		

