

























Original	Replacement
 Power	 Power
 Input Selector	 AV
 FM/AM	 Shift + 1
 TV	 Shift + 2
 DVD Recorder	 Shift + 3
 BD/DVD Player / Analog 8CH	 Shift + 4
 Cable / Sat	 Shift + 5
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0

Original	Replacement
 >10	 Guide
 Direct Tuning	 Ok
 CH+	 Ch +
 CH+	 Up
 CH-	 Down
 CH-	 Ch -
 Vol+	 Vol +
 Vol-	 Vol -
 Muting	 Mute
 Drive Select	 Media
 Tune-	 Left
 << PORT	 <<
 Tune+	 Right
 >> PORT	 >>
 Stop PORT	 Stop
 Pause PORT	 Pause
 Play PORT	 Play





Original	Replacement	Original	Replacement
 I<< PORT	 I<<		
 >>I PORT	 >>I		
 One Touch Play	 Smart		
 Surround Off	 Shift + Red		
 PLIIX	 Red		
 NEO:6	 Green		
 SFC Music	 Yellow		
 SFC Movie	 Blue		
 Test / Auto	 Text		
 Sound Menu	 Dual		
 Display	 Info		
 Option Port /	 Options		
 TV Vol+	 Shift + Vol +		
 TV Vol-	 Shift + Vol -		
 TV/Video	 TV/R		





Original	Replacement
 Power	 Power
 Input Selector	 AV
 FM/AM	 Shift + 1
 DVD Power	 Shift + Power
 TV	 Shift + 2
 DVD Recorder	 Shift + 3
 BD/DVD Player / Analog 8CH	 Shift + 4
 Cable / Sat	 Shift + 5
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9

Original	Replacement
 0	 0
 >10	 Guide
 CH+	 Ch +
 CH-	 Ch -
 Vol+	 Vol +
 Vol-	 Vol -
 Muting	 Mute
 Drive Select	 Media
 <<	 <<
 >>	 >>
 Stop	 Stop
 Pause	 Pause
 Play	 Play
 I<<	 I<<
 >>I	 >>I
 One Touch Play	 Smart
 Top Menu / Direct Navigator	 List








Original	Replacement
Functions DVD Recorder	+ Shift + Menu
Functions DVD Player	Menu
Up	Up
Left	Left
OK	Ok
Right	Right
Down	Down
Sub Menu	D. Menu
Return	Back
Surround Off	+ Shift + Red
PL IIx	Red
NEO:6	Green
SFC Music	Yellow
SFC Movie	Blue
Test / Auto	Text
Sound Menu	Dual
Display	Info

Original	Replacement
Option Port /	Options
TV Vol+	+ Shift + Ch +
TV Vol-	+ Shift + Ch -
TV/Video	TV/R





Original	Replacement
 Power	 Power
 Input Selector	 AV
 FM/AM	 Shift + 1
 TV Power	 Shift + Power
 TV	 Shift + 2
 DVD Recorder	 Shift + 3
 BD/DVD Player / Analog 8CH	 Shift + 4
 Cable / Sat	 Shift + 5
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9

Original	Replacement
 0	 0
 >10	 Guide
 CH+	 Ch +
 CH-	 Ch -
 Vol+	 Vol +
 Vol-	 Vol -
 Muting	 Mute
 Drive Select	 Media
 One Touch Play	 Smart
 Functions	 Menu
 Up	 Up
 Left	 Left
 OK	 Ok
 Right	 Right
 Down	 Down
 Sub Menu	 D. Menu
 Return	 Back





Original	Replacement
Surround Off	Shift + Red
PL IIx	Red
NEO:6	Green
SFC Music	Yellow
SFC Movie	Blue
Test / Auto	Text
Sound Menu	Dual
Display	Info
Option Port /	Options
TV Vol+	Shift + Ch +
TV Vol-	Shift + Ch -
TV/Video	TV/R

Original	Replacement







Original	Replacement
 Power	 Power
 Input Selector	 AV
 FM/AM	 Shift + 1
 Power	 Shift + Power
 TV	 Shift + 2
 DVD Recorder	 Shift + 3
 BD/DVD Player / Analog 8CH	 Shift + 4
 Cable / Sat	 Shift + 5
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9

Original	Replacement
 0	 0
 CH+	 Ch +
 CH-	 Ch -
 Vol+	 Vol +
 Vol-	 Vol -
 Muting	 Mute
 Drive Select	 Media
 One Touch Play	 Smart
 Surround Off	 Shift + Red
 PL IIx	 Red
 NEO:6	 Green
 SFC Music	 Yellow
 SFC Movie	 Blue
 Test / Auto	 Text
 Sound Menu	 Dual
 Display	 Info
 Option Port /	 Options





Original	Replacement	Original	Replacement
	TV Vol+  + 		
	TV Vol-  + 		
	 TV/R		

