











Original	Replacement	Original	Replacement
 Power	 Power	 0	 0
 Title / Disc Menu	 Text	 Vol -	 Vol -
 Function Tv	 AV	 Vol +	 Vol +
 Red	 Red	 I<<	 I<<
 Green	 Green	 Tv Ch -	 Ch -
 Yellow	 Yellow	 Mute	 Mute
 Blue / Tuner	 Blue	 Pause	 Pause
 1 / PLII	 1	 >>I	 >>I
 2 / DSP-EQ	 2	 Tv Ch +	 Ch +
 3 / MO-ST	 3	 <<	 <<
 4 / Repeat	 4	 Stop	 Stop
 5 / CD Ripping	 5	 Play	 Play
 6 / Dimmer	 6	 >>	 >>
 7 / Info	 Info	 Menu	 Menu
 7 / Info	 7	 Return	 Back
 8	 8	 Up / Tunning +	 Up
 9	 9	 Down / Tunning -	 Down





Original	Replacement	Original	Replacement
 Power	 Power	 Vol -	 Vol -
 Function Tv	 AV	 Vol +	 Vol +
 Red	 Red	 I<<	 I<<
 Green	 Green	 Tv Ch -	 Ch -
 Yellow	 Yellow	 Mute	 Mute
 Blue / Tuner	 Blue	 Pause	 Pause
 1 / PLII	 1	 >>I	 >>I
 2 / DSP-EQ	 2	 Tv Ch +	 Ch +
 3 / MO-ST	 3	 <<	 <<
 4 / Repeat	 4	 Stop	 Stop
 5 / CD Ripping	 5	 Play	 Play
 6 / Dimmer	 6	 >>	 >>
 7 / Info	 Info	 Menu	 Menu
 7 / Info	 7	 Return	 Back
 8	 8	 Up / Tunning +	 Up
 9	 9	 Down / Tunning -	 Down
 0	 0	 Right	 Right



