

































































































Original	Replacement
	 Power
	 Red / Netflix / Search
	 Mute / Dimmer
	 Green / APP / Repeat
	 Yellow / YouTube / Repeat
	 Blue / Prime Video / Random
	 Sleep / Timer
	 Exit / Cancel / Clear
	 Display / Media
	 Back / Return
	 Shift + TV/Radio / Program
	 Audio / Lang I/II
	 Text / Goto
	 AV / Input / RDS
	 Up
	 CH+ / Page+
	 Down

Original	Replacement
	 CH- / Page-
	 Right
	 Left
	 Vol-
	 Menu / Home
	 OK
	 1
	 2
	 3
	 4
	 5
	 6
	 7
	 8
	 9
	 Guide / EPG / -/-
	 0





Original	Replacement
 Last	 Shift + Back / Return
 P.STD	 Smart / List
 S.STD	 Eject / Surround
 ARC	 Stop / Hold
 STILL	 Pause / Step / Freeze
 Zoom-	 Zoom / Size
 Zoom+	 Setup / OPT /
 Multi-PiP	 TV/Radio /
 Size	 Shift + Zoom /
 S.Swap	 Subtitle / EQ
 Win-Sel	 D.Menu / Top
 Locate	 Sound / Title
 Swap	 Picture / Format

Original	Replacement

