



Original	Replacement	Original	Replacement
	Power		Power
	TV		9
	Text		9
	Source 2		<< / Tune-
	Source 1		>> / Tune+
	1		Shift + CH- /
	2		0
	3		Shift + CH+ /
	Contrast-		Guide / EPG / -/-
	Contrast+		Left
	4		Right
	5		Vol-
	6		Vol+
	Brightness-		CH- / Page-
	Brightness+		CH+ / Page+
	7		Sound / Title
	8		Audio / Lang I/II
			Zoom / Size
			Mute / Dimmer



