



Original	Replacement	Original	Replacement
Yellow/Info	Yellow / YouTube / Repeat	Mute	Mute / Dimmer
Power	Power	1	1
Green/[...]	Green / APP / Repeat	2	2
Blue/Title	Blue / Prime Video / Random	3	3
Red/Audio	Red / Netflix / Search	4	4
Up	Up	5	5
Purple/Camera	Smart / List	6	6
Left	Left	7	7
OK	OK	8	8
Right	Right	9	9
Down	Down	AV	AV / Input / RDS
Return	Back / Return	0	0
Menu	Menu / Home	<<	<< / Tune-
Vol+	Vol+	Play	Play / Slow
+/PR+	CH+ / Page+	>>	>> / Tune+
Vol-	Vol-	Zoom / Rec	Rec / Rec Mode
-/PR-	CH- / Page-	Zoom / Rec	Zoom / Size







































Original	Replacement
Open/Close	Eject / Surround
Yello/Info	Yellow / YouTube / Repeat
Yello/Info	Info / Angle
Power	Power
Marker	Fav / Marker / PC
Surround	Shift + Eject / Surround
Green/[...]	Green / APP / Repeat
Green/[...]	Subtitle / EQ
Blue/Title	Blue / Prime Video / Random
Blue/Title	Sound / Title
Prog/Random	Setup / OPT /
Repeat	Shift + Green / APP /
Red/Audio	Red / Netflix / Search
Up	Up
Purple/Camera	Smart / List
Purple/Camera	Shift + Info / Angle
OO	Display / Media

Original	Replacement
Left	Left
OK	OK
Right	Right
Down	Down
Return	Back / Return
Menu	Menu / Home
Vol+	Vol+
+/PR+/>>	CH+ / Page+
+/PR+/>>	>> / Preset+
Vol-	Vol-
-/PR-/ <<	CH- / Page-
-/PR-/ <<	<< / Preset-
Mute	Mute / Dimmer
1	1
2	2
3	3
4	4





Original	Replacement
 Open/Close	 Eject / Surround
 Yellow/Info	 Yellow / YouTube / Repeat
 Power	 Power
 Marker	 Fav / Marker / PC
 Green/[...]	 Green / APP / Repeat
 Blue/Title	 Blue / Prime Video / Random
 Prog/Random	 Setup / OPT /
 Red/Audio	 Red / Netflix / Search
 Up	 Up
 Purple/Camera	 Smart / List
 Left	 Left
 OK	 OK
 Right	 Right
 OO	 Display / Media
 Return	 Back / Return
 Down	 Down
 Menu	 Menu / Home

Original	Replacement
 Vol+	 Vol+
 +/PR+	 CH+ / Page+
 Vol-	 Vol-
 -/PR-	 CH- / Page-
 Mute	 Mute / Dimmer
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 AV	 AV / Input / RDS
 0	 0
 <<	 << / Tune-



