







































































Original	Replacement	Original	Replacement
 Power	 Power	 6	 6
 Tv/TXT	 Text	 7	 7
 Input	 AV	 8	 8
 OK	 Ok	 9	 9
 Up	 Up	 0	 0
 Down	 Down	 Back	 Back
 Right	 Right	 FAV	 Shift + Pre Ch
 Left	 Left	 Menu	 Menu
 Vol+	 Vol +	 Exit	 Exit
 Vol-	 Vol -	 Nicam/A2	 Shift + Guide
 CH+	 Ch +	 Display	 Shift + Info
 CH-	 Ch -	 Mute	 Mute
 1	 1	 Picture	 Format
 2	 2	 Sound	 Dual
 3	 3	 Sleep	 Sleep
 4	 4	 Subtitle	 Subt
 5	 5	 EPG	 Guide





	Original	Replacement		Original	Replacement
	CH/List	 Pre Ch			
	Red	 Red			
	Green	 Green			
	Yellow	 Yellow			
	Blue/Screen	 Blue			
	Play	 Play			
	Pause	 Pause			
	Stop	 Stop			
	Record	 Rec			
	>>/Size	 >>			
	<</Hold	 <<			
	Cancel	 Shift + Back			
	Reveal/Rep	 Eject			
	I<</Subpage	 D. Menu			
	>>I/Index	 Info			
	List	 List			

