



| Original | Replacement | Original | Replacement                 |
|----------|-------------|----------|-----------------------------|
|          | Power       |          | Power                       |
|          | Dtv/Vcr     |          | Display / Media             |
|          | 1           |          | 1                           |
|          | 2           |          | 2                           |
|          | 3           |          | 3                           |
|          | 4           |          | 4                           |
|          | 5           |          | 5                           |
|          | 6           |          | 6                           |
|          | 7           |          | 7                           |
|          | 8           |          | 8                           |
|          | 9           |          | 9                           |
|          | Menu        |          | Menu / Home                 |
|          | 0           |          | 0                           |
|          | Exit        |          | Exit / Cancel / Clear       |
|          | Red         |          | Red / Netflix / Search      |
|          | <<          |          | << / Tune-                  |
|          | Up          |          | Up                          |
|          | Ch+         |          | CH+ / Page+                 |
|          | Green       |          | Green / APP / Repeat        |
|          | >>          |          | >> / Tune+                  |
|          | Left        |          | Left                        |
|          | Vol-        |          | Vol-                        |
|          | Ok          |          | OK                          |
|          | Right       |          | Right                       |
|          | Vol+        |          | Vol+                        |
|          | Yellow      |          | Yellow / YouTube / Repeat   |
|          | Down        |          | Down                        |
|          | Ch-         |          | CH- / Page-                 |
|          | Blue        |          | Blue / Prime Video / Random |
|          | Mute        |          | Mute / Dimmer               |
|          | Pause       |          | Pause / Step / Freeze       |
|          | Favorite    |          | Fav / Marker / PC           |
|          | Recall      |          | Back / Return               |
|          | Lang        |          | Shift + Audio / Lang I/II   |



