



| Original | | Replacement | | Original | | Replacement | |
|---|--------|---|-----------------------------|---|------------|---|-----------------------|
|  | Power |  | Power |  | TV |  | Shift + 1 |
|  | 1 |  | 1 |  | Up / P+ |  | Shift + Up |
|  | 2 |  | 2 |  | Up / P+ |  | Up |
|  | 3 |  | 3 |  | AV |  | AV / Input / RDS |
|  | 4 |  | 4 |  | Left / V- |  | Left |
|  | 5 |  | 5 |  | Left / V- |  | Shift + Left |
|  | 6 |  | 6 |  | Menu |  | Menu / Home |
|  | 7 |  | 7 |  | Menu |  | Shift + Menu / |
|  | 8 |  | 8 |  | Right / V+ |  | Right |
|  | 9 |  | 9 |  | Right / V+ |  | Shift + Right |
|  | Mute |  | Mute / Dimmer |  | S / M / D |  | Exit / Cancel / Clear |
|  | 0 |  | 0 |  | Down / P- |  | Shift + Down |
|  | 16:9 |  | Picture / Format |  | Down / P- |  | Down |
|  | Red |  | Red / Netflix / Search |  | Recall |  | Back / Return |
|  | Green |  | Green / APP / Repeat |  | Recall |  | Shift + Back / Return |
|  | Yellow |  | Yellow / YouTube / Repeat |  | i |  | Info / Angle |
|  | Blue |  | Blue / Prime Video / Random |  | EQ |  | Subtitle / EQ |





| Original | Replacement |
|---|--|
|  |  Shift + Info / Angle |
|  |  Sound / Title |
|  |  Text / Goto |
|  |  Setup / OPT / |
|  |  Stop / Hold |
|  |  Zoom / Size |
|  |  Sleep / Timer |
|  |  D.Menu / Top |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

| Original | Replacement |
|----------|-------------|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

