







































































Original	Replacement	Original	Replacement
	Power		Power
	16:9		Picture / Format
	Mute		Mute / Dimmer
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Back		Back / Return
	Repeat		Shift + Green / APP /
	List Fav		Smart / List
	List Fav		Fav / Marker / PC
	Exit		Exit / Cancel / Clear
	Reveal / EPG		Guide / EPG / -/-
	Source		AV / Input / RDS
	Info		Info / Angle
	Menu		Menu / Home
	Red		Red / Netflix / Search
	Up		Up
	Yellow		Yellow / YouTube / Repeat
	Left		Left
	OK		OK
	Right		Right
	Green		Green / APP / Repeat
	Down		Down
	Blue		Blue / Prime Video / Random
	Vol+		Vol+
	P+		CH+ / Page+
	Vol-		Vol-





Original		Replacement		Original		Replacement	
	P-		CH- / Page-				
	TTX		Text / Goto				
	Rec		Rec / Rec Mode				
	T-Shift		Sleep / Timer				
	AD		Shift + Audio / Lang I/II				
	Index / Play/Pause		Play / Slow				
	Zoom / Stop		Zoom / Size				
	Zoom / Stop		Stop / Hold				
	Hold / I<<		Shift + Stop /				
	Hold / I<<		I<< / Preset-				
	Language / >>I		Sound / Title				
	Language / >>I		>>I / Preset+				
	Subtitle		Subtitle / EQ				
	Audio		Audio / Lang I/II				

