







































































Original	Replacement	Original	Replacement
 Power	 Power	 Blue/[]	 Blue
 Vol+	 Vol +	 Info	 Info
 Vol-	 Vol -	 Text	 Text
 PR+	 Ch +	 1	 1
 PR-	 Ch -	 2	 2
 Mute	 Mute	 3	 3
 Menu	 Menu	 4	 4
 Exit	 Exit	 5	 5
 Back	 Back	 6	 6
 OK	 Ok	 7	 7
 Up	 Up	 8	 8
 Down	 Down	 9	 9
 Right/Zoom+	 Right	 0	 0
 Left/Zoom-	 Left	 AV	 AV
 Red/[o]	 Red	 SP/LP	 Media
 Green/Timer/List	 Green	 Play	 Play
 Yellow	 Yellow	 >>	 >>







































































Original	Replacement	Original	Replacement
REV	<<		<<
STOP	Stop		Stop
PAUSE	Pause		Pause
REC	Rec	REC MODE	Rec
MARK	Mark	ECO 3D	3D
0000	0000	-/~/GUIDE	Guide





Original	Replacement	Original	Replacement
			
Power	Power	Blue/[]	Blue
			
Vol+	Vol +	Info	Info
			
Vol-	Vol -	Text	Text
			
Mute	Mute	Play	Play
			
PR+	Ch +	Stop	Stop
			
PR-	Ch -	Rec	Rec
			
Exit	Exit	Pause	Pause
			
Menu	Menu	>>	>>
			
Back	Back	<<	<<
			
Up	Up	1	1
			
Down	Down	2	2
			
Right/Zoom+	Right	3	3
			
Left/Zoom-	Left	4	4
			
OK	Ok	5	5
			
Red/[o]	Red	6	6
			
Green/Timer/List	Green	7	7
			
Yellow	Yellow	8	8





Original		Replacement	
	9		9
	AV		AV
	SP/LP		Media

Original		Replacement	





Original	Replacement	Original	Replacement
	Power		Blue/[]
	Vol +		Info
	Vol -		Text
	Mute		1
	Ch +		2
	Ch -		3
	Menu		4
	Exit		5
	Back		6
	Up		7
	Down		8
	Right		9
	Left		0
	Ok		AV
	Red		Media
	Green		Play
	Yellow		Stop





Original	Replacement	Original	Replacement
	>>		>>
	<<		<<
	Rec		Rec
	Pause		Pause
	Mark		3D
	0000		Guide

