













Original	Replacement
 Power	 Power
 Tv/Rad	 TV/Radio /
 Tv/SAT	 Smart / List
 Red/Opt	 Red / Netflix / Search
 Red/Opt	 Setup / OPT /
 Green/A/V+	 Green / APP / Repeat
 Yellow/FAV	 Yellow / YouTube / Repeat
 Yellow/FAV	 Fav / Marker / PC
 Blue/A-Z	 Blue / Prime Video / Random
 Menu	 Menu / Home
 EPG	 Guide / EPG / -/--
 Info	 Info / Angle
 Up	 Up
 Left	 Left
 OK	 OK
 Right	 Right
 Down	 Down

Original	Replacement
 V+	 Vol+
 Recall	 Back / Return
 P+	 CH+ / Page+
 V-	 Vol-
 P-	 CH- / Page-
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 Pause	 Pause / Step / Freeze
 0	 0
 Mute	 Mute / Dimmer

